



Front Tow Hook Adapter Install Instructions

Honda Civic Type R 2017+

Install Time: 0.5~1 Hr

Install Instructions:

1. Remove the front bumper cover.
2. Unbolt the forward horn. Add the supplied 5mm spacer and remount the horn to the side.



3. Remove the lower two bolts on the crash support beam



4. Mount the Tow Hook Adapter using the supplied 50mm bolts as shown below.



5. Trim the front grill for the tow rod access.



6. Reinstall front bumper cover.
7. Install the tow hook or plate holder of your choice. The thread pitch required is M22 x 2.50. A rod length of at least 95mm is desired.



Thank you for your order!
Tag us on Instagram!
@EVSTuning | #evstuning