



Rear Bumper Cap Install

Honda S2000 2000-2003 AP1

Packing List:

- Tapping Screw x 3
- 3M Double Sided Adhesive Tape Roll x 1
- AP1 Rear Bumper Cover x 1

1. Thoroughly clean the surface area of the bumper where the cover will be applied to.
2. Cut and apply the roll of 3M tape as pictured below. **It is important to not apply the tape all the way to the edge.**



3. Peel off all 3M tape backing and line up the cover to the bumper. Before applying any pressure, please be sure the cover is lined up. Once desired fitment is achieved you may apply pressure. For improved adhesion, use clamps to secure the cover.



4. It is recommended to use the pre-drilled holes on each end of the cover as a template and drill the holes for the securing hardware.



Thank you for your order!
Tag us on Instagram!
@EVSTuning | #evstuning